

## Fabric Shaver



Instruction Manual

Live Chat Anytime at [1byonebros.com](http://1byonebros.com) or Register your product for free at [1byonebros.com/wpr](http://1byonebros.com/wpr) to extend your warranty to full **2 years** and refund guarantee to **90 days!**

### Safety Instructions


- This product is only authorized for domestic use and only intended for applications described in these instructions.
- Children should not use, clean, or perform maintenance on the fabric shaver without adult supervision.
- Do not expose or submerge the shaver in water. Do not use the fabric shaver on moist fabrics.
- Make sure no foreign objects penetrate the shaver.
- Do not attempt to open the shaver's housing, except the battery compartment to replace batteries and shaver foil to clean cutting blades.
- Remove the batteries if you do not intend to use the shaver for a long period of time.
- If the batteries leak, remove them immediately and clean the battery compartment with a dry cloth.
- Do not throw the batteries into fire. Do not recharge the batteries to avoid explosion.
- Always keep batteries out of the reach of infants and young children to prevent them from being swallowed. If swallowed, take immediate action and contact medical authorities for help.

### Included Items

- 1x Fabric Shaver  
1 x Replaceable Cutting Blades  
1 x Power Adapter  
1x Cleaning Brush  
1x Instructional Manual

Before using the fabric shaver for the first time, check the package contents to ensure all parts are free of visible damage.

### Product Description



- |                              |                               |
|------------------------------|-------------------------------|
| 1. ON/OFF/Speed Switch       | 7. Adjustable Spacer          |
| 2. Battery Compartment Cover | 8. Replaceable Cutting Blades |
| 3. Fluff Collector           | 9. Cleaning Brush             |
| 4. DC-IN Jack                | 10. Power Adapter             |
| 5. Cutting Blades            |                               |
| 6. Shaver Foil               |                               |

### Choosing the Power Supply

- This fabric shaver is powered by 4 AA batteries or connected by an AC power adapter.

**NOTE:** When inserting the batteries in, make sure the ribbon inside of the compartment is underneath the batteries for better removal of batteries.

**IMPORTANT:** When using the fabric shaver powered by batteries, remove the power adapter from the fabric shaver or else the shaver won't work.

### Preparing for Use

- Before removing fluff, always test on a small area of the fabric that is not publicly visible to confirm the speed level is appropriate for the fabric

### How to Use Beautural Fabric Shaver?

1. Lay the garment over a hard surface such as a table top. This ensures the fabric will not gather and accidentally be damaged during shaving.
2. Stretch a small area of fabric with one hand during shaving and keep the shaving head at a 90 degree angle to the fabric.

**Note:** Empty the fluff collector regularly. The fluff collector should never be more than 3/4 full or it will slow the cutting blades.

## Shaving Tips



### For Knitted Fabrics

Guide the shaver in the direction of the knitting.



### Fabrics with Accessories

Avoid shaving over any accessories.



### Thin Garments

Fold into two layers and lay over an ironing board.



### Quick Shaving

Slide the shaver around over the top of the garment.




## Tips for Using Spacer


- Use the shaver with spacer when removing large bobbles and coarse textiles, small lint and fine textiles.
- Remove the spacer from shaver when removing very small lint/bobbles, only for shaving very fine textiles.

## How to Remove/Attach the Spacer?

- **To Remove the Spacer** - Hold the shaver with one hand, put your thumb on the top of the spacer, pull the spacer forward, and remove it.




- **To Attach the Spacer** - Place it on the cutting head and press it firmly. Make sure the tab on the bottom of the spacer fits into the recess on the shaver.




## How to Replace the Cutting Blades

- **To Remove the Cutting Blades** - Unscrew the shaver foil, carefully grasp the cutting blades' edge and pull them out, avoiding damage to your hands.



- **To Attach the Cutting Blades** - Grasp the cutting blades' edge and firmly insert the cutting blades into shaver body. Finally, screw the shaver foil back into place.



## Emptying the Fluff Collector

1. Pull the fluff collector a little way down and lift it off.
2. Empty the textile fluff.
3. Place the fluff collector back on the shaver.

## Maintenance and Care

1. Unscrew the shave foil and spacer and clean them using a slightly damp cloth.
2. Use the officially-provided cleaning brush to remove fluff and lint remnants from the cutting blades.
3. Screw the shaver foil back on when all parts are completely dry.
4. Place the spacer back on the shaver.

### Note:

- Never use any corrosive liquids. These may damage the surface of the shaver.
- Be careful when handling the cutting blades. They are very sharp and can easily be damaged.

## Specifications

Model: 1-MR02US02, LT-0005

Power Supply: 4 x 1.5V type AA batteries

Voltage: 6V

Power Adapter:

Input: 100-240V~50-60Hz 0.2A

Output: 6V = 1A



This product's packaging is made from environmentally friendly material and can be disposed of at your local recycling plant.

## Customer Service

### US

Phone: +1 909-391-3888 (Mon-Fri 9:00am - 5:00pm PST)

Email: ushelp@1byonebros.com

### CA

Email: cahelp@1byonebros.com

1byone Products Inc.

1230 E Belmont Street, Ontario, CA, USA 91761

Customer Service: +1 909-391-3888

www.1byonebros.com